



# HP Spectre 13-3010dx Back Case Removal

Use this prerequisite guide to take off the back case of your HP Spectre 13-3010dx.

Written By: Laurisa Titterud



## INTRODUCTION

This is a prerequisite guide to replacing the battery, charge port, fan, (and others TBD).

---


### **TOOLS:**

- [iFixit Opening Tools](#) (1)
  - [T4 Torx Screwdriver](#) (1)
-

## Step 1 — Removal of the Back Case



- Put on Anti Static Wrist Strap.

 It is always a good idea to ground yourself when working with electronics to prevent static buildup. You wear this strap to protect you and your device from accidental electrostatic discharge (ESD) damage during repairs.]

- Flip Computer Upside down.
- Unscrew the eight 3.3mm black screws on the back casing with the T4 Torx Screwdriver.

## Step 2



- Use the plastic opening tool to lift the back case off.
- ⓘ Use the plastic opening tools first; metal spudgers can damage your device.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-22 04:54:14 AM.